

Find the right product for your application



Damaged Metal Parts

- LOCTITE® EA 3463™
- LOCTITE® EA 3478™
- LOCTITE® EA 3471™
- LOCTITE® EA 3473™
- LOCTITE® PC 7222™

Damaged Rubber Parts

- LOCTITE® PC 7350™
- LOCTITE® PC 7383™



Damaged Metal Parts



EA 3463™ Repair Epoxy Stick

Fast Repair

Working Time: 3 minutes

Cure Speed: 10 minutes

Substrate: Metal
Form: Kneadable Putty



EA 3478™ Superior Metal

High Performance

Working Time: 20 minutes

Cure Speed: 6 Hours

Substrate: Metal
Form: Trowelable



EA 3471™ Steel Putty

Steel Filled Epoxy

Working Time: 30 minutes

Cure Speed: 6 Hours

Substrate: Metal
Form: Trowelable



EA 3473™ Fast Set Steel Putty

Fast Curing

Working Time: 4 minutes

Cure Speed: 10 minutes

Substrate: Metal
Form: Trowelable



PC 7222™ Wear Resistant Putty

Abrasion-resistant

Working Time: 30 minutes

Cure Speed: 6 Hours

Substrate: Metal
Form: Trowelable