



The tolerance of installation



The method of assembly



1. Adjust the face of A and A' at same space
2. Adjust Hub's Minimum space
3. Assemble the bolts in the order of 2-2', 5-5', 3-3', 4-4', 6-6', 1-1'
4. Assemble the bolts in the middle part of the edge



1. Adjust the face of A and A' at same space
2. Adjust Hub's Minimum space
3. Assemble the bolts in the order of 2-2', 7-7', 3-3', 6-6', 1-1', 4-4', 8-8', 5-5'
4. Assemble the bolts in the middle part of the edge