

Finer Chain Breakers offer an easy and convenient way of breaking riveted roller chain links. Suitable for both British Standard and ASA chain.

Finer No.1 Chain Breaker (25-60 Chain Breaker)

Suitable for  $\frac{1}{4}$ " –  $\frac{3}{4}$ " chain

Finer No.2 Chain Breaker (60-100 Chain Breaker)

Suitable for  $\frac{3}{4}$ " –  $1\frac{1}{4}$ " chain



## To use chain puller

- 1) Hook the two jaws into each end of the chain;
- 2) Turn the screw until the two ends almost meet;
- 3) Insert the connecting link and fasten.

Finer No.1 Chain puller (25-60 Chain puller)

Finer No.2 Chain puller (60-100 Chain puller)



Tip: To avoid unnecessary bending of link plates, press pins out evenly. Pop the rivet of the first pin and then the second, when both pins have been "cracked", proceed with fully pushing the pins out.