


JR, IM..P



JR.JS1

Shaft dia.	Boundary dimensions(mm)			Part No.	Mass
	d	F	B		
7	7	10	16	JR7x10x16	0.005
9	9	12	16	JR9x12x16	0.006
12	12	15	16	JR12x15x16	0.008
14	14	17	17	JR14x17x17	0.009
17	17	20	20	JR17x20x20	0.014
20	20	25	20	JR20x25x20	0.028
25	25	30	20	JR25x30x20	0.034
30	30	35	20	JR30x35x20	0.039
35	35	40	20	JR35x40x20	0.046
40	40	45	20	JR40x45x20	0.052
45	45	50	25	JR45x50x25	0.073
50	50	60	25	JR50x60x25	0.17